


INVERTER-1 Unit


INVERTER 1



INVERTER 1 UNIT
DUNTKC471UJ05
(PWBXC471WJ)


INVERTER-2 Unit

INVERTER 2



INVERTER 2 UNIT
_DUNTKC472UJ05
(PWBXC472WJ)

INVERTER 3



INVERTER-4 Unit

INVERTER 4

